




DESIGN RF	DRAWN BY RF	DART AEROSPACE LTD HAWKESBURY, ONTARIO, CANADA	
CHECKED #	APPROVED #	DRAWING NO. DEO 9183	REV. B SHEET 1 OF 1
DATE 00.05.15		TITLE ADD SKIDTUBE P/N D2580-045	SCALE NTS
A	00.03.29	NEW ISSUE	
B	00.05.15	39.580 WAS 39.620	

DART ENGINEERING ORDER

AMEND DRAWING D2580 REV. C TO ADD D2580-045 ASSEMBLY

D2580-045 IS IDENTICAL TO D2580-041, EXCEPT FOR THE FOLLOWING CHANGES:

- 1) INSTALL CROSS BOLT SPACERS AT LOCATIONS MARKED 'X' ACCORDING TO THE FOLLOWING PROCEDURE.
 - a) DRILL $\varnothing 0.508$ HOLES AT LOCATIONS SHOWN BELOW MARKED 'X'. CHAMFER HOLES $0.030 \times 45^\circ$. NOTE THAT HOLES WILL ALSO HAVE TO BE TRANSFERRED TO THE D2596 WEB AT THE * LOCATIONS. IT IS ACCEPTABLE TO PRE-DRILL THE D2596 WEB IN THESE LOCATIONS BEFORE INSTALLING THE WEB IN THE SKIDTUBE. OPEN HOLES TO $\varnothing 0.63$ AND TOUCH UP WITH ALODINE PER QSI 005 4.1.
 - b) INSERT D2579 CROSS BOLT SPACERS INTO THE HOLES.
 - c) WELD INTO PLACE PER DART QSI 004 AND GRIND FLUSH.
 - d) REMOVE SPILL OVER LEAVING HOLE DIMENSION $\varnothing 0.380$ - $\varnothing 0.390$.
- 2) IT IS ACCEPTABLE TO GRIND A RELIEF IN THE D2855 AFT CAP TO PREVENT INTERFERENCE WITH THE SPACER AT THIS LOCATION.
- 3) POWDER COAT ENTIRE ASSEMBLY GREEN (REF. 4.3.5.8) PER DART QSI 005 4.3 INSTEAD OF WHITE (REF. 4.3.5.1).



Copyright © 2000 by DART AEROSPACE LTD

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.